



SMT PCB Handling Machine AC 220V Automatic PCB Magazine Loader

Our Product Introduction

for more products please visit us on smtmachine-spareparts.com

Basic Information

- Place of Origin: China
- Brand Name: GS
- Model Number: GS LD-250/GS LD-330/GS LD-390/GS LD-460
- Minimum Order Quantity: 1 PCS
- Price: USD+negotiable+PCS
- Packaging Details: 2000*1000*1400mm
- Delivery Time: 1-7 days
- Payment Terms: T/T
- Supply Ability: 1000+PCS+per days



Product Specification

- Specification 1: GS LD-250
- Specification 2: GS LD-330
- Specification 3: GS LD-390
- Specification 4: GS LD-460
- Power Supply: AC 220V/ 50/60Hz
- Air Supply: 5 Kg F/cm²
- PCB Size 1 (mm): 330*50~250
- PCB Size 2 (mm): 445*50~330
- PCB Size 3 (mm): 530*50~390
- PCB Size 4 (mm): 535*50~460
- PCB Transport Direction: Customize Left To Right Or Right To Left
- Magazine Size 1 (mm): 335*320*565
- Magazine Size 2 (mm): 460*400*565
- Magazine Size 3 (mm): 535*460*565
- Magazine Size 4 (mm): 535*530*565



Product Description

PCB Handling Machine PCB Loader PCB Magazine Loader For SMT | GSSMT, PCB Handling Equipment, PCB Loader Machine, PCB Unloader Machine, SMT Handling System, PCB Conveyor System, PCB Transfer Machine, Automated PCB Handling, PCB Buffer System, PCB Handling Automation, PCB Handling Solutions, PCB Handling Machine

Here's how to operate the PCB magazine loader when changing products in the SMT line:

1. Manual Running: Press the manual running button and select the pitch between PCBs.
2. Adjust Magazine Width: Set the magazine width to match the new PCB, ensuring smooth insertion.
3. Load Magazine: Place a magazine into the loader.
4. Box Input: Press the box input to move the magazine to the lift platform.
5. Clamping and Lift Down: Click clamping, then lift down. The magazine will lower to the position for unloading the first board.
6. Adjust Pusher: Use the rocker to center the pusher on the PCB line. Ensure easy manual push from rail to magazine. The magazine layer should be about 1mm lower than the rail.
7. Check Push Plate: Click the push plate to verify if the machine can store PCBs from the rail into the magazine.
8. Automatic Running: Click exit, then automatic running. The machine will be ready and wait for the board signal.

Global Soul Limited

sales@gs-smt.com





Global Soul Limited

+8613728696610

liyi@gs-smt.com

smtmachine-spareparts.com

Room F3B-016, B Block, Hao Yun Lai Bussiness Building, Liutang road , Bao'an District , Shenzhen, China