



Automatic PCB Handling Machine with 300W Main Motor and AC 220V Power Supply for SMT Line

Our Product Introduction

for more products please visit us on smtmachine-spareparts.com

Basic Information

- Place of Origin: China
- Brand Name: GS
- Model Number: GS LD-250/GS LD-330/GS LD-390/GS LD-460
- Minimum Order Quantity: 1 PCS
- Price: USD+negotiable+PCS
- Packaging Details: 2000*1000*1400mm
- Delivery Time: 1-7 days
- Payment Terms: T/T
- Supply Ability: 1000+PCS+per days



Product Specification

- Specification 1: GS LD-250
- Specification 2: GS LD-330
- Specification 3: GS LD-390
- Specification 4: GS LD-460
- Power Supply: AC 220V/ 50/60Hz
- Air Supply: 5 Kg F/cm²
- PCB Size 1 (mm): 330*50~250
- PCB Size 2 (mm): 445*50~330
- PCB Size 3 (mm): 530*50~390
- PCB Size 4 (mm): 535*50~460
- PCB Transport Direction: Customize Left To Right Or Right To Left
- Magazine Size 1 (mm): 335*320*565
- Magazine Size 2 (mm): 460*400*565
- Magazine Size 3 (mm): 535*460*565
- Magazine Size 4 (mm): 535*530*565



Product Description

SMT PCB Handling Machine AC 220V Automatic PCB Magazine Loader

PCB Handling Equipment | PCB Loader Machine | PCB Unloader Machine | SMT Handling System | PCB Conveyor System | PCB Transfer Machine | Automated PCB Handling | PCB Buffer System | PCB Handling Automation | PCB Handling Solutions

Operation Instructions

Manual Running: Press the manual running button and select the pitch between PCBs.

Adjust Magazine Width: Set the magazine width to match the new PCB for smooth insertion.

Load Magazine: Place a magazine into the loader.

Box Input: Press the box input to move the magazine to the lift platform.

Clamping and Lift Down: Click clamping, then lift down to position for unloading the first board.

Adjust Pusher: Use the rocker to center the pusher on the PCB line. Ensure magazine layer is about 1mm lower than the rail.

Check Push Plate: Click the push plate to verify PCB storage from rail into magazine.

Automatic Running: Click exit, then automatic running to wait for board signal.





Global Soul Limited



+8613728696610



liyi@gs-smt.com



smtmachine-spareparts.com

Room F3B-016, B Block, Hao Yun Lai Bussiness Building, Liutang road , Bao'an District , Shenzhen, China