





# High Viscosity 4 Strips SMT Splice Tape 32mm - 88mm GSM19 Series

## **Basic Information**

Place of Origin: China Brand Name: GS

Model Number: GSM1908Minimum Order Quantity: 1 PCS

• Price: USD+negotiable+pcs

Packaging Details: 6\*45\*10mm
Delivery Time: 1-7 days
Payment Terms: T/T

• Supply Ability: 1+pcs+per days



## **Product Specification**

Brand Name: GSMaterial: PETModel Number: GSM1908

Dimensions (pc): 4.5/2/2/4.5mm X 40mm
Product Name: SMT Splice Tape
Application: SMT Process
Customization: Support
Lead Time: 1-7 Days

Highlight: High Viscosity SMT Splice Tape,
 SMT Splice Tape 32mm



# More Images



## **Product Description**

### GSM19 Series Special High Viscosity 4 Strips SMT Splice Tape

#### **DESCRIPTION**

GSM19 series SMT 4 splice tape with guide alignment designed apply for all sizes(8mm/12mm/16mm/24mm/32mm/44mm/56mm/72mm/88mm) of carrier tape. It is made of 4 pcs tapes, release paper and removable PET with superior adhesion.

#### 1, Application

- 1. Joining SMT Carrier Tapes: The splice tape is used to join strips of PET tape for carrier tapes ranging from 8mm to 88mm in width. This allows for continuous operation without the need to frequently reload the feeder.
- 2. Compatibility with Various Machines: The splice tape is suitable for use with a variety of SMT machines, including those from Universal, Juki, Sanyo, and Hitachi, among others.
- 3. 4 splice tapes design.
- 4. 32mm-88mm available upon request.

#### 2, Detailed Instructions for Use

To maximize the benefits of the GSM19 series SMT 4 splice tape, it is essential to follow the correct usage procedures. Below is a step-by-step guide to using the splice tape effectively:

- 1. Cutting the Carrier Tapes: Use the appropriate cutting tool (GSMTL20, GSMTL30, or GSMTL40) to accurately cut the carrier tapes to the desired length.
- 2. Preparing the Splice Tape: Remove the release liner from the splice tape to expose the adhesive side.
- 3. Aligning the Carrier Tapes: Place the cut carrier tapes (with the cover tape facing down) onto the splice guide placement to ensure proper alignment.
- 4. Folding the Splice Tape: Fold over the other strip of the splice tape to the underside of the carrier tape and press firmly to secure the joint.
- 5. Removing the Guide: Once the tapes are joined, remove the guide placement from the carrier tapes.
- 6. Finalizing the Splice: Remove and discard the clear plastic cover to complete the splicing process.
- 7. Ensuring Reliable Splicing: Press down firmly on the splice tape to ensure a reliable and secure splice.

Special High Viscosity 4 Strips SMT Splice Tape GSM19 Series | GSSMT, SMT double splice tape, SMT double splice tape for pick-and-place, SMT double splice tape yellow, SMT double splice tape suppliers, Double splice tape for SMT machines, SMT double splice tape adhesive, SMT double splice tape black, SMT double splice tape usage guide, SMT double splice tape for feeders, High-quality SMT double splice tape, SMT double splice tape price, SMT splice tape double-sided, Double splice tape for Panasonic SMT, Double splice tape for Fuji SMT, SMT double splice tape compatibility, Double splice tape for high-speed SMT machines, SMT double splice tape performance, SMT double splice tape durability, SMT splice tape double strength, SMT double splice tape best practices





+8613728696610



liyi@gs-smt.com



e smtmachine-spareparts.com

Room F3B-016, B Block, Hao Yun Lai Bussiness Building, Liutang road, Bao'an District, Shenzhen, China